



**NUMBER:** 23-032-02

**GROUP:** Body

**DATE:** Jun. 24, 2002

*This bulletin is supplied as technical information only and is not an authorization for repair. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, or otherwise, without written permission of DaimlerChrysler Corporation.*

**SUBJECT:**

Instrument Panel Mat (Pencil Tray) Adhesion

**OVERVIEW:**

This bulletin involves installing a revised instrument panel mat.

**MODELS:**

2002 (PL) NEON

**NOTE: THIS BULLETIN APPLIES TO VEHICLES BUILT PRIOR TO APRIL 18, 2002 (MDH 0418XX).**

**SYMPTOM/CONDITION:**

The instrument panel mat (pencil tray) may be separating from the instrument panel.

**DIAGNOSIS:**

Inspect the instrument panel mat for separation from the instrument panel. If mat is separating perform the Repair Procedure.

**PARTS REQUIRED:**

Qty.	Part No.	Description
1	0SD63WL5AB	Mat, Instrument Panel, Taupe
1	0SD63XDVAB	Mat, Instrument Panel, Slate

**REPAIR PROCEDURE:**

1. Remove the existing mat from the instrument panel and discard. The use of a fiber (trim) stick may be necessary to assist in the removal of the mat.
2. Clean the instrument panel surface with a clean cloth and isopropyl alcohol (single application).
3. Install the revised mat using finger pressure and/or a roller.

**POLICY:**

Reimbursable within the provisions of the warranty.

**TIME ALLOWANCE:**

Labor Operation No:	Description	Amount
23-11-15-93	Mat, Instrument Panel Replace	0.2 hrs.

**FAILURE CODE:**

P8	New Part
----	----------